

HORUS

TECHNICAL DATA SHEET

Product:

HORUS Castable

Page: 1/3

Version: 1

Date: 09.01.2024

Horus Castable ® Resin



Fast

Accurate

Castable

1. PRODUCT DETAILS

1.1. Product description

HORUS Castable is a photopolymerizable resin with low viscosity and high reactivity intended to be used with SLA, DLP or MSLA devices in the range of 365-405 nm. This resin is intended to be used by professionals for high-definition castable moulds fabrication. Printed parts offer high dimensional stability for enhanced precision. Furthermore, no residual ash remains after calcination.

1.2. Availability

1.2.1. Packaging

HORUS Castable is available in 1L bottle.

1.2.2. Colour

HORUS Castable is available in orange colour.



2. PRODUCT PROPERTIES

2.1. Liquid properties

Physical properties of liquid HORUS Castable are shown in the following table:

Property	Unit	Method	Value
Viscosity (23°C)	cP	ISO 1628	250
Density (23°C)	g.cm^{-3}	Internal	1,12
Polymerization shrinkage	%	Internal	0,4

2.2. Properties after printing and post-processing

When parts are printed with Horus S-One and post-processed using Clean & Cure S-One according to the instruction for use workflow, the final properties of HORUS Castable are indicated in the following table:

Property	Unit	Method	Value
Flexural strength	MPa	ISO 178	> 50
Flexural modulus	GPa	ISO 178	> 1,5
Hardness	Shore D	ISO 868	> 75

Some slight variation may occur from a batch to another

3. WORKFLOW

Information on the HORUS Castable workflow, from part designing to post-processing including product handling, filling of the resin tank and printing, are available in the instruction for use which is highly recommended to read.

4. STORAGE

HORUS Castable should be kept in the original bottle, closed and stored at a temperature between 10°C and 28°C in a dry place away from light. A small light amount may indeed be sufficient to initiate polymerization. After use, HORUS Castable can be put back in the original bottle using a filter with a maximum mesh size of 200 µm to avoid any contamination. HORUS Castable must not be used after the expiry date.

5. WASTE MANAGEMENT

Fully cured parts can be considered as plastic waste and are not harmful for the environment. However, the liquid resin must be disposed of as a chemical product in accordance with local regulations. Finally, empty packaging must be brought to an approved waste treatment site for recycling or disposal.

6. ADDITIONAL INFORMATION

In addition to this technical data sheet, it is strongly recommended to read the HORUS Castable instruction for use and safety data sheet. Information provided in this instruction for use are based on our knowledge and experience of HORUS Castable in our dental laboratory at the date of this instruction for use. In order to produce optimum quality parts, the process phases indicated in this instruction for use must be strictly followed.

If defect appear in HORUS Castable within the warranty period, the user may only claim replacement of the material. 2MS is not liable in any way for any loss or damaged caused by HORUS Castable, whether direct or indirect damage including collateral damage, regardless of the legal basis. 2MS is only liable for direct material damages of HORUS Castable based on deliberate act or gross negligence of its legal representatives or executive staff for personal damage in accordance with the statutory regulations. 2MS cannot be held responsible for the material or for any damage resulting from its use if the user has not followed the specified procedure.

HORUS is a brand of eco-responsible 3D printing resins designed and manufactured in France. The Coq Vert label from ADEME and BPI France attests to our commitment to the ecological and energy transition while the French Fab, French Tech and French Care labels bear witness to our desire to develop French industry and embody an innovative, ambitious and healthcare France. The HORUS research and development centre combines the expertise of chemists and dental 3D printing experts to guarantee continuous improvement of our products and meet all dental needs. Especially, HORUS strives not to use controversial molecules such as bisphenol A (BPA), methyl methacrylate (MMA), tetrahydrofurfyl methacrylate (THFMA) and 2,4,6-Trimethylbenzoyl-diphenylphosphine oxide (TPO) which are still widely used by major actors in the dentistry field.



+ 33 (0)9.72.01.82.82



www.horus3d.fr



460 Av de la Quiera, Voie K, Lot 119a, Mouans-Sartoux 06370



849.563.069.00020



info@horus3d.com



2MS

HORUS

